


Service
Service
Service



42 931 A12

Safety regulations require that the set be restored to its original condition and that parts which are identical with those specified be used.

Service Manual

⑤ SPECIFICATION

Microprocessor	: Z80A
Memory	: 48k ROM 16k disk ROM 128k video RAM 128k user RAM
Video processor	: V9938
MSX controller	: S-3527
Floppy-disk drive	: 3.5" 1 MB
Interfaces	: RF output (UHF channel E36) Monitor output SCART Cassette recorder 2 joystick Printer 2 cartridge slots
Keyboard	: QWERTY/00/16
Power supply voltage	: 220 V ± 10%, 50Hz

⑥ SPECIFICATIE

Microprocessor	: Z80A
Geheugen	: 48k ROM 16k disk ROM 128k video RAM 128k gebruikers RAM
Video processor	: V9938
MSX controller	: S-3527
Floppy-disk drive	: 3.5" 1 MB
Interfaces	: RF uitgang (UHF kanaal E36) Monitor uitgang SCART Cassette recorder 2 handbedieningen Printer 2 cartridge sleuven
Toetsenbord	: QWERTY/00/16
Voedingsspanning	: 220 V ± 10%, 50Hz

⑦ CARACTERISTIQUES TECHNIQUES

Microprocesseur	: Z80A
Mémoire	: 48k ROM 16k ROM à disque 128k RAM vidéo 128k RAM utilisateur
Processeur vidéo	: V9938
Contrôle MSX	: S-3527
Lecteur de disquette	: 3.5" 1 MB
Interfaces	: Sortie RF (Canal UHF E36) Sortie monitor SCART Magnétophone cassette 2 poignées Imprimante 2 "slots" cartouche
Clavier	: QWERTY/00/16
Tension d'alimentation	: 220 V ± 10%, 50Hz

⑧ TECHNISCHE DATEN

Microprocessor	: Z80A
Speicher	: 48k ROM 16k Disk-ROM 128k Video-RAM 128k Gebruikers-RAM
Videoprocessor	: V9938
MSX-Stuureinheit	: S-3527
Floppy Disk-Laufwerk	: 3.5" 1 MB
Schnittstellen	: RF Ausgang (UHF Kanal E36) Monitorausgang SCART Cassettenrecorder 2 Handbedienungen Drucker 2 Kassettenschlitze
Tastatur	: QWERTY/00/16
Versorgungsspannung	: 220 V ± 10%, 50Hz

① DATA TECNICI

Microprocessore	: Z80A
Memoria	: 48k ROM 16k ROM A disco 128k RAM video 128k RAM utilizzatori
Processore video	: V9938
MSX di controllo	: S-3527
Lettore di dischetto	: 3.5" 1 MB
Interfacce	: Uscita RF (Canale UHF E36) Uscita monitor SCART Registratore a cassetta 2 leve manuali Stampa 2 connettori per cartucce
Tastiera	: QWERTY/00/16
Tensione di aliment.	: 220 V ± 10%, 50Hz

Documentation Technique Service Dokumentation Documentazione di Servizio Huolto-Ohje Manual de Servicio Manual de Servicio



Subject to modification
4822 727 16027
Printed in The Netherlands
© Copyright reserved

PHILIPS

Published by
Consumer Electronics

CS 11 823

**CAUTION**

1. The exchange of cartridges should take place with the set turned off.

2. ESD



All ICs and many other semi-conductors are susceptible to electrostatic discharges (ESD). Careless handling during repair can reduce life drastically.
When repairing, make sure that you are connected with the same potential as the mass of the set via a wrist wrap with resistance.
Keep components and tools also at this potential.

ADJUSTMENTS**VDP Clock frequency**

- Connect a frequency counter to 8-U15 via a 10:1 probe.
- Adjust TC2 for a frequency of $3,554,685 \pm 200$ Hz on 8-U15.

FDC**1. Read-pulse width**

- Connect an oscilloscope to 29-U8 via a 10:1 probe.
- Switch the computer on.
- Connect 22-U8 to ground.
- Adjust the pulse width on 29-U8 for 400 ± 100 ns with the aid of VR1, see figure 1.
- Interrupt the connection between 22-U8 and ground.

2. VCO frequency

- Connect a frequency counter to 16-U8 via a 10:1 probe.
- Switch the computer on.
- Connect 22-U8 to ground.
- Adjust the frequency on 16-U8 for 255 ± 5 kHz with the aid of VR2.
- Interrupt the connection between 22-U8 and ground.

RTC clock frequency

- Connect a frequency counter to 17-U13 via a 10:1 probe.
- Adjust TC1 for a frequency of 32.768 kHz on 17-U3.

Encoder unit

- Connect a frequency counter to 17-U1 via a 10:1 probe.
- Adjust TC1 for a frequency of $4,433,619 \pm 20$ Hz on 17-U1.

Floppy Disk Drive**1. Required measuring equipment**

- Dual trace oscilloscope, for example PM3211.
- Alignment disk, code number 4822 395 30274.
- FDD test cartridge, code number 4822 397 30171.

2. Use of the FDD test cartridge

- Switch the computer off and insert the FDD cartridge.
- Switch the computer on again.
- Type: "CALL FDDTEST" and press the <RETURN> key.
- Select the disk drive test.
- The functions in the disk drive test are used for adjusting the disk drive.

3. Radial alignment

- Connect channel A of the oscilloscope via a 10:1 probe with test point TP1 (for a survey of the test points, see figure 2).
- Connect channel B via a 10:1 probe with test point TP2.
- Connect the mass terminal of the probe with TP3.
- Oscilloscope alignments:
 - Trigger externally with the index signal (on connector J1, pin 1).
 - Sensitivity time basis: 20 ms/div.
 - Sensitivity channel A and channel B: 5mV/div.
 - Invert channel B.
 - Add channel A and channel B.
- Place the alignment disk in the drive and read track 40, side 0 (with <F3>).
- Check that the cat's eye pattern (see figure 3) is visible on track 40.
- If the correct cat's eye pattern is not visible, stop the reading action (with <ESC>).
- Loosen the screws A (see figure 4) of the stepping motor a quarter turn.
- Read track 40, side 0 continuously (with <F3>).
- Rotate the stepping motor until all lobes of the cat's eye pattern have the same amplitude.
- Tighten the screws A of the stepping motor again and check the cat's eye pattern once more. Repeat the alignment, if necessary.
- Stop the reading action with <ESC>.
- Read track 00, side 0 (with <F3>) and increase the track number with the <CURSOR UP> key to track 40.
- Check the cat's eye pattern again.
- Stop the reading action (with <ESC>).
- Read track 79, side 0 (with <F3>) and lower the track number to track 40 with the <CURSOR DOWN> key.
- Check the cat's eye pattern again.

4. Alignment track 00 sensor**Method 1**

- First check the radial alignment.
- Carry out point A of the radial alignment, however with the sensitivity of the time base at 5 μ s/div. and trigger on channel A.
- Insert the alignment disk into the drive and read track 00, side 0 (with <F3>).
- Check whether a 62.5 kHz signal (a '1F' data pattern) is present on track 00.
- If the signal is not present, loosen the screw of the track 00 sensor a quarter turn and adjust the track 00 sensor until the 62.5 kHz signal will be visible.
- Tighten the screw of the track 00 sensor again.
- Check if the 62.5 kHz signal is only present on track 00 and not on track 01.

Method 2

- First check the radial alignment.
- Connect the input of the oscilloscope with test point TP5 and ground.
- Insert a disk into the drive and read track 00, side 0 (with <F3>).
- Increase the track number to track 02 (with the <CURSOR UP>key) and measure the voltages across the track 00 sensor. These voltages should be:
 - 3.5V on track 00
 - 1.5V on track 01
 - 0.5V on track 02
- If the measured values do not correspond with the values given above, decrease the track number by 1 to track 01.
- Loosen the screw of the track 00 sensor a quarter turn.
- Adjust the track 00 sensor until the voltage across the sensor is 1.5V at track 01.
- Tighten the screw of the track 00 sensor again.
- Check the voltages across the sensor at track 00, track 01 and track 02.

5. Azimuth inspection

- Carry out point A of the radial alignment, however with the sensitivity of the time base at 0.5 ms/div.
- Place the alignment disk into the drive and read track 40, side 0 (with <F3>).
- Check the azimuth burst wave pattern (see figure 5).
- A tolerance of $\pm 30^\circ$ is allowed. Greater deviations may cause compatibility problems. The head unit cannot be adjusted further.

6. Index burst alignment

- Connect channel A of the oscilloscope via a 10:1 probe with test point TP1.
- Connect channel B via a 10:1 probe with the index signal (on connector J1, pin 1).
- Connect the mass terminal of the probe, connected to channel A, with TP3.
- Oscilloscope alignments:
 - Trigger on channel B.
 - Sensitivity time base: 0.1 ms/div.
 - Sensitivity channel A: 2 mV/div.
 - Sensitivity channel B: 0.2V/div.
- Loosen the screw of the index sensor a quarter turn.
- Insert the alignment disk into the floppy drive and read track 40, side 0 (with <F3>).
- Adjust the index sensor so, that the period time T becomes $400 \pm 200 \mu\text{s}$ (see fig. 6).
- Tighten the screw of the index sensor again and check the alignment once more.

7. Side 1

- Check alignments 3 to 6 for side 1.

8. Speed of spindle motor

- Connect an oscilloscope via a 10:1 probe to connector J1, pin 1 (index) and connect the mass terminal of the probe with TP3.
- Adjust the period time of the index pulse for $200 \pm 0.5 \text{ ms}$ by means of a screwdriver in alignment point A (see figure 7) of the spindle motor.




Fig. 1




Fig. 2

MDA.00886
T28/746

FDD PARTS LIST

1	4822 535 92418	Spindle motor
2	4822 404 60409	Holder assy
3	4822 432 10645	Front
4	4822 358 20269	Belt
6	4822 212 22884	Complete PCB
7	4822 404 60411	Bracket
8	4822 362 10265	Stator stepper motor
9	4822 362 20234	Rotor stepper motor




Fig. 3 39 578 A12




Fig. 4




Fig. 6




Fig. 7 MDA. 00885







Fig. 5 39 580 A12

WIRING DIAGRAM







ELECTRICAL DIAGRAM FDD



42 948 B12

FUNCTIONAL DIAGRAM






X0	X1	X2	X3	X4	X5	X6	X7
0	1	2	3	4	5	6	7
8	9	-	=	[	]	R	1
				2025			
				/		A	B
C	D	E	F	G	H	I	J
K	L	M	N	O	P	Q	R
S	T	U	V	W	X	Y	Z
CHN					F1	F2	F5
F4	F5	END	TUR	STOP	NO DEF		
UP/OK	DOWN	DEL		←	↑	↓	→
↑							
	CONF						
					CODE		


49	46	41	37	33	28	26	21	17	13
0	0	0	0	0	0	0	0	0	0
47	43	38	33	31	27	23	19	15	11
50	45	42	39	34	30	26	22	18	14
0	0	0	0	0	0	0	0	0	0
45	41	40	36	32	28	24	20	16	12


2	8	15	14	66	27	36	30	34	30	8
0	0	0	0	0	0	0	0	0	0	0
4	8	12	12	25	28	28	32	32	37	8
1	5	13	17	21	28	28	32	32	37	8
0	0	0	0	0	0	0	0	0	0	0
2	7	11	12	18	23	23	28	35	39	8

POS. NR.	TYPE	DESCRIPTION	+5V	↓
U0	28.514	6 ST. ADDRESS	10	2
U10	28.516	8 INSTRUCTIONS	10	2
U11	28.564	DATA ADDRESS	10	2


[illegible]

















9 20 21 22 23 24 25 26 27 28




PRS C2096
T32 744
NMS6245

19 20 21 22 23 24 25 26 27 28

BP1 H22
C1 K26
C10 L20
C11 D27
C12 G21
C13 H22
C14 H21
C15 H22
C16 H23
C17 H22
C18 M01
C19 M02
C2 L25
C20 M19
C21 J20
C22 J20
C24 L25
C25 G25
C3 B24
C4 C24
C42 H 7
C44 L 4
C45 E 4
C46 L 5
C47 L 5
C48 L 6
C49 B 8
C5 C24
C52 B 9
C53 B10
C56 B10
C6 I20
C65 H16
C66 H16
C67 B 6
C7 H20
C8 H20
C9 K19
DL1 J22
L1 G20
L2 G26
L3 K17
L4 E12
L5 F12
L6 G12
Q1 C26
Q10 F12
Q11 G12
Q12 J10
Q14 I 9
Q2 C26
Q3 D26
Q4 L24
Q7 G 5
Q8 D12
R F
R1 L24
R10 C25
R11 C26
R12 C26
R13 D25
R14 E26
R15 D26
R16 D27
R17 G25
R18 L23
R19 H21
R2 L26
R20 H21
R21 J21
R22 J22
R23 L24
R24 K20
R25 L20
R26 D27
R3 B25
R4 B24
R5 B24
R56 H 3
R57 H 5
R58 D 5
R59 G 5
R6 B25
R60 H 5
R63 K 8
R64 K 7
R65 K 7
R66 I 8
R67 I 9
R68 E12
R69 F12
R7 B25
R70 H12
R71 J11
R8 C25
R83 G 4
R84 G 4
R9 C25
RF1 J26
TC1 J19
TC2 L 5
U1 G20
U14-1 H 4
U14-2 H 4
U14-3 G 3
U15 C 6
U16 C 8
U17 C 9
U18 C10
U19 C10
X1 J19
X3 L 6




POWER SUPPLY




42 719 B12

LED PANEL



42 717 A12

PAL ENCODER




MAIN PRINTED BOARD


U...			 		
U100	Main printed board (/00/16 1)	4822 219 81089	D1-D6	MA165	4822 130 32362
			ZD1	HZ3CLL	4822 130 33009
			VD1	Vari. cap SVC203-M	4822 125 11009
					
U1	Z80A	4822 209 10569	C6, C9 C10, C13 C15 C19 C35, C39 C37, C64 C49, C52 C53, C56 TC1, TC2 Tantal Mylar Mylar Mylar Mylar Mylar Tantal Trimmer 22 µF 16 V 220 nF 50 V 10 nF 50 V 22 nF 50 V 3n3 50 V 22 µF 16 V 30 pF 4822 124 10527 4822 121 42931 4822 121 90038 4822 121 42417 4822 121 42784 4822 124 10527 4822 125 50299		
U2	M60003A	4822 209 71325			
U3	81464-12	4822 209 83426			
U4	81464-12	4822 209 83426			
U5	81464-12	4822 209 83426			
U6	81464-12	4822 209 83426			
U7	ROM/00/16	4822 209 72581			
U8	2793	4822 209 11146			
U9	74LS14	5322 209 85199			
U10	7416	5322 209 84035			
U11	S-3527	4822 209 11097	VARIOUS X1 X2 X3 BT1 RY1 ST1 4 MHz 32.768 kHz 21.328125 MHz Ni-CD accumulator Relay Service jumper 4822 242 72073 4822 242 71345 4822 242 71347 4822 138 10235 4822 280 60514 4822 276 11572		
U12	UPC311	5322 209 85503			
U13	RP5C01	4822 209 83431			
U14	74LS04	5322 209 81625			
U15	V9938	4822 209 83425			
U16	81464-12	4822 209 83426			
U17	81464-12	4822 209 83426			
U18	81464-12	4822 209 83426			
U19	81464-12	4822 209 83426			
U20	MN1280	4822 209 83414			
RA2	8x4k7	4822 116 90191			
VR1	50 k Trimmer	4822 100 11106			
VR2	10 k Trimmer	4822 100 11105			
Q1-Q4	2SC3330	4822 130 60945			
Q5-Q7	2SA1317	4822 130 60944			
Q9-Q12	2SC3330	4822 130 60945			
Q14	2SA1317	4822 130 60944			
Q15	2SA720A	4822 209 11045			
Q16	2SA1317	4822 130 60944			

1) Install jumper JP2 and remove jumper JP1 for /16 version.

POWER SUPPLY

U...			U...		
U101	Power supply board	4822 219 81091	U102	Encoder unit	4822 219 81092
					
U1	STR2005	4822 209 70871	IC1	MC1377	4822 209 71415
U2	UPC7812HF	4822 209 72579			
U3	MC7812CT	4822 209 81726	Q1-Q4	2SC3330	4822 130 60945
 					
D1-D4	S2V-10	4822 130 32814	R24	43k 1%	4822 111 41359
D5-D8	MPG06G	4822 130 80631	R25	10k 1%	4822 111 41358
					
L1	Coil	4822 157 52805	C10	1nF 50 V film	4822 121 42945
L2	180 μ	4822 157 53326	TC1	30pF trimmer	4822 125 50299
LED PANEL			VARIOUS		
U...			BP1	Transformer	4822 157 53332
U103	Complete LED panel	4822 219 81118	DL1	Delay 400 nS	4822 157 53327
			X1	4.433619 MHz	4822 242 72074
LD1	LED yellow	4822 130 32984	Modulator		4822 212 10215
LD2	LED green	4822 130 32983	CN2	Monitor connector	4822 267 50711
LD3	LED green	4822 130 32983	FLOPPY DISK DRIVE		
VARIOUS			U...		
SW1	Reset switch	4822 277 10862	U104	Floppy disk drive	4822 212 22883
	Reset knob	4822 410 24402			






42 786 D12

MECHANICAL PARTS LIST

1	4822 410 24402	Reset Knob
2	4822 219 81118	LED panel
3	4822 432 10643	Cabinet top case
4	4822 219 81088	Keyboard /00
	4822 219 81093	Keyboard /16
6	4822 219 81091	Power supply
7	4822 276 12322	Mains switch
8	4822 432 10644	Cabinet bottom case
9	4822 219 81092	Encoder unit
11	4822 404 60413	PCB support
12	4822 267 50604	SCART connector
13	4822 404 60412	Slot guide
14	4822 146 30646	Transformer
16	4822 267 60167	Connector (50p)
17	4822 265 20264	AC inlet
18	4822 212 22883	Floppy drive
19	4822 267 50709	Printer connector
21	4822 267 50711	Recorder connector
22	4822 267 70168	Connector (50p)
23	4822 219 81089	Main panel/00/16
24	4822 267 30915	Joystick connector

MEMORY LAY-OUT



SYMBOLS USED IN CIRCUIT DIAGRAMS

SYMBOL	TYPE	P_{70° amp	TOLERANCE	SERIES
	SFR16T	0.5	1E - 3M 5%	E24
	SFR25H	0.5	1E - 10M 5%	E24
	MRS25	0.6	1E - 1M 1%	E24
	MR30	0.5	1E - 1M 1% (2%)	E24
	VR37	0.5	220K - 33M 5%	E24
	PR37	1.6	1E - 1M 5%	E24
	VR68	1	100K - 68M 5%	E24
	MRS 16T	0.4	10R - 100K	E24/E96

SYMBOL	TYPE	VOLTAGE DC	TOLERANCE
	POLYESTER FLATFOIL	SEE NOTE	10%
	PLATE CERAMIC	SEE NOTE	DEPENDING ON CAPACITY
	ELCO MINIATURE SINGLE	SEE NOTE	-10+50%
	ELCO SINGLE ENDED	SEE NOTE	±20%

NOTE:

*	f = 25V	q = 200V	x = 1000V	E = 20V
	g = 40V	r = 250V	z = 1600V	F = 35V
a = 2.5V	h = 63V	s = 300V	A = 16V	G = 50V
b = 4V	j = 100V	t = 350V	B = 6V	H = 75V
c = 6.3V	l = 125V	u = 400V	C = 12V	I = 80V
d = 10V	m = 150V	v = 500V	D = 15V	
e = 16V	n = 160V	w = 630V		

39 301 A13

